





Nebula Capsule / Nebula Capsule Pro Quick Start Guide

Overview


Front View




Rear View




Top View



Bottom View



Remote Control





LED Indication


Indicator	Description
Solid blue	· Operating in projector mode · Bluetooth connected (Bluetooth speaker mode)
Flashing blue	Ready to pair / Bluetooth pairing (Bluetooth speaker mode)
Solid red	Charging
Solid green	Fully charged

Getting Started

- Place your projector on a flat and stable surface, and squarely point it to face the projection surface.
- Slide off the battery cover and install 2 AAA batteries before using the remote control for the first time. Make sure the positive and negative ends are facing the correct polarity direction as marked in the battery compartment.
- Use the provided cable and charger to fully charge the built-in battery before operating for the first time.





- Hold **⏻** for 2 seconds on the projector to turn it on.
- Adjust the focus using the focus adjustment knob.
- For first-time use, follow the on-screen instructions to complete the basic setup. Adjust the settings in the projector's **Settings** menu if necessary.
- Download the Nebula Connect app to control the projector.



Using the Nebula Capsule

- To play video from HDMI playback devices:
 - Connect this projector to an HDMI playback device with an HDMI cable (not provided).
 - Press **⏠** to open the home menu, select **[HDMI]**, and press **OK**.
 - The device will automatically start HDMI playback when connected to an HDMI playback device for the first time.
- To enjoy music, video, and photos from a USB storage device:



- ① Press  to access the home menu.
- ② Select [**File Manager**] and press **OK**.
- ③ Select a file, then press **OK**.

To get a full user manual, visit: <https://us.seenebula.com/products/d4111>

Um eine vollständige Bedienungsanleitung zu erhalten, besuchen Sie die Website: <https://us.seenebula.com/products/d4111>

Pour obtenir un manuel d'utilisation complet, visitez le site Web: <https://us.seenebula.com/products/d4111>

Para obtener un manual de usuario completo, visite el sitio web: <https://us.seenebula.com/products/d4111>

Per ottenere un manuale utente completo, visitare il sito Web: <https://us.seenebula.com/products/d4111>

完全なユーザーマニュアルを入手するには、Webサイトを参照してください: <https://us.seenebula.com/products/d4111>

للحصول على دليل مستخدم كامل ، قم بزيارة موقع الويب: <https://us.seenebula.com/products/d4111>

Notice

Declaration of Conformity

 This product complies with the radio interference requirements of the European Community.

Hereby, Anker Innovations Limited, declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the Declaration of Conformity, visit the Web site <https://uk.seenebula.com>

Due to the used enclosure material, the product shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

The adapter shall be installed near the equipment and shall be easily accessible.

Do not use the Device in the environment at too high or too low temperature, never expose the Device under strong sunshine or too wet environment.

The suitable temperature for the product and accessories is 5°C-35°C.

When charging, please place the device in an environment that has a normal room temperature and good ventilation.

It is recommended to charge the device in an environment with a temperature that ranges from 5°C~25°C.

Please ensure to use only the charger offered by the manufacturer. Using unauthorized charger may cause danger and violate the authorization of the projector and the guarantee article.

This charger is for indoor use only.

The charger type is Q183, output voltage/current is 9Vdc/2A. The plug considered as disconnect device of adapter.

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20 cm between the device and the human body.

To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device and human body. CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

BT Maximum output power: 7.97 dBm;

BT Frequency band: 2402~2480 MHz;

Wi-Fi Max Output Power: 19.20 dBm (2.4G);12.57 dBm (5G);

Wi-Fi Frequency Band: 2412~2472 MHz (2.4G); 5150~5250 MHz, 5725~5850 MHz (5G).

5150~5250 MHz can be used indoor only.

Anker Innovations Deutschland GmbH | Georg-Muche-Strasse 3, 80807 Munich, Germany

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

 Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

 This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling.

Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

FCC Notice

This device complies with the FCC rules, Part 15. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the partly responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party
Company Name: Fantasia Trading LLC
Address: 5350 Ontario Mills Pkwy, Suite 100, Ontario, CA 91764
Telephone:1-800-988-7973

UK CA

This product complies with the radio interference requirements of the United Kingdom Declaration of Conformity Hereby, Anker Innovations Limited declares that the product type D4111 is in compliance with Radio Equipment Regulations 2017. The full text of the UK declaration of conformity is available at the following internet address: uk.seenebula.com

모델명 : D4111

인증번호 : R-C-All-D4111

제품명 : 특정소출력 무선기기 (무선데이터통신시스템용 무선기기)

제조자및제조국가 : Anker Innovations Limited

제조년월 : 2021.05

해당 무선설비는 운용 중 전파혼신 가능성이 있음 . 해당

무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된

서비스는 할수 없음 .